

### What's Included

## Welcome

Thank you for choosing Arlo. Getting started is easy.



100% wireless camera



Lithium 123 batteries



Magnetic wall mount



Mounting screw

## Insert Batteries


- Unlock the battery compartment by sliding and holding the latch.
- Slide the battery door back and lift it to open the compartment.



3. Insert two batteries near the back of the camera.



4. Insert two batteries near the compartment hinge.



. Close the battery door.



5

## Sync Your Camera with a Base Station

Bring the camera within one to three feet of the base station.
Your base station will look like one of the following.



- Press the **Sync** button on the side of the base station for two seconds. Release the button.
- 3. Wait for the sync status LED to blink green.



 $\overline{\phantom{a}}$ 

- 4. Press the **Sync** button on top of the camera for two seconds.
- 5. Release the button.

Note: Cameras must be synced one at a time.



A blue LED on the camera blinks slowly when starting the sync process. The blue LED blinks rapidly to confirm sync.

The camera is ready for viewing.

Note: The LED blinks amber if the sync is not successful. You must repeat the sync process.



9

### Add Your Camera to Your Arlo Account

- Launch the Arlo app from your smartphone, log in, and click or tap Add Device.
  If you are using a computer, visit arlo.netgear.com.
- Follow the onscreen instructions.



#### You're Done!

Congratulations!

Your Arlo camera is set up and ready to go.

To view useful tutorial videos, find troubleshooting tips, or get support, visit *arlo.com/support*.



©NETGEAR, Inc., NETGEAR, the NETGEAR Logo, and Arlo are trademarks of NETGEAR, Inc.

#### Compliance

For the current EU Declaration of Conformity, visit http://kb.netgear.com/app/answers/detail/a\_id/11621/.

For regulatory compliance information, visit http://www.netgear.com/about/regulatory/.

# **NETGEAR®**

350 East Plumeria Drive San Jose, CA 95134, USA





201-19465-03

February 2017