

BATTERYCAM2

USER GUIDE



Document SAP 102041715-01

WHAT'S IN THE BOX



Battery Cam



USB power adapter



USB cable



1x Screwpack



Bracket option 1




Bracket option 2



Guide


CAMERA OVERVIEW



Power port	DC 5V±10%
Power on/off	Press the button for 3 seconds to turn on/off the camera.
Status light	<p>Flashing red light Slow flashing: Power. Waiting for network connection. Fast flashing: Connecting to the network.</p> <p>Solid blue light on Camera is working correctly.</p> <p>Solid red light on Camera has an issue.</p>
SD card slot	Supports local MicroSD card storage (Max.128GB).
Reset	Press and hold for 5 seconds to reset the camera.
Charging indicator	<ul style="list-style-type: none"> Solid red indicator on: battery is charging. Solid blue indicator on: charging completed.
Battery capacity	9600mAh


INSTALLATION

Bracket option 1



1. Fix bracket to the wall using the screws provided.
2. Slowly bring the camera closer to the bracket and the camera will snap to the bracket with a magnet.

Bracket option 2



1. Fix the bracket on the wall.
2. Install the camera in the bracket and lock it with the screw.

Standards and Compliance

EN 55032:2015/A11:2020	EN IEC 61000-3-2:2019/A1:2021
EN 55035:2017/A11:2020	EN 61000-3-3:2013/A2:2021 /AC:2022-01
EN 50130-4:2011/A1:2014	

DOWNLOAD HOMECONTROL2.0



<https://bit.ly/2Pi2G7N>



Biometric login



Detailed history of events



Constantly evolving



Step-by-step setup



Geofence alerts



Live camera feeds

ADDING A CAMERA

LOG IN TO YOUR ACCOUNT


If you are already logged in your account, skip straight to the 'Add the Camera' section.




1. Tap the hamburger icon in the bottom right corner.



2. Select 'Login' from the settings options.



3. Log in using your HomeControl Cloud credentials.



Create an Account

If you do not already have a PyronixCloud account, you can create one on this page by selecting 'Create One' at the bottom of the page.

Once you have click on this, fill out your details and create a login.


ADD THE CAMERA



1. Tap the red '+' button in the bottom menu bar.



2. Select 'Add video doorbell / camera' from the list.



3. Select 'Battery camera' from the list.



4. Follow the on screen instructions to add the battery camera.

BATTERYCAM2 SUPPORT

The Support HUB page for Wi-Fi cameras can be accessed by scanning the QR code below or navigating to the URL below it.



www.support.pyronix.com/uk/products/category/wifi-cameras

Battery Information

The batteries supplied have been chosen to provide long service life whilst, for safety reasons, having limited output current. When disposing of the product, the battery must be removed and disposed of separately in accordance with the local regulations.

Product Warning Information

For electrical products sold within the European Community. At the end of the electrical products life, it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

To prevent possible damage to components, any static charge on your body needs to be eliminated before touching the inside of the unit. This can be accomplished by touching some grounded/earthed metallic conductor such as a radiator / pipework immediately before replacing the batteries.

Pyronix Limited

Secure House, Braithwell Way, Hellaby, Rotherham, S66 8GY, United Kingdom