

EURO-OEM16R+PSU

Remote output expander; 16 way relay outputs with 2.5A power supply.



EN50131-3:2009
EN50131-1:2006+A1:2009
EN50131-6:2008
Security Grade 3
Environmental Class II



ENGLISH

References:

A CHANGE OUTPUTS (Programming Menu Required)

B Only required when powered with battery only

C LEDs:
Power = Green
RS485-in = Blue: Flashing = Data OK. Solid = Not addressed.
Off = No data
A-Fault = For future use.
RS485-out = Blue
P-Fault = Red. Flashing = Battery or PSU fault

D Do not common the D2+ to the control panels 12V+ supply.

Specification

Supply voltage: 9-15VDC
Current consumption: 25mA, Max 340mA when all relays active
PGM1-PGM16: Programmable
PGM1-PGM16 type: Relay 3A, Max 30V.
PGM1-PGM16 normal state: Changeover NC & NO
PGM1-PGM16 active state: Changeover NC & NO
Power supply rating: 2.0A Continuous and 2.5A when charging
Transformer rating: 44VA
Dimensions Box (H x W x D): 390 x 305 x 100mm
Dimensions PCB (H x W x D): 215 x 125 x 65mm
Front and rear tamper protected with one tamper switch
PD6662:2010 (12hrs standby if notified to an ARC). For 17Ah=1350mA.
EN50131-1:2006+A1:2009 (30hrs if notified to an ARC). For 17Ah=497mA
EN50131-1:2006+A1:2009 (60hrs if not notified to an ARC). For 17Ah=248mA

Warranty

This product is sold subject to our standard warranty conditions and is warranted against defects in workmanship for a period of two years (batteries excluded). In the interest of continuing care and design, Castle/Pyronix Ltd reserves the right to amend specifications, without giving prior notice.

Product Warning Information

For electrical products sold within the European Community. At the end of the electrical products life, it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

Compatible Products

The EURO-OEM16R+PSU can be connected to the following control panels/devices:

- EURO 46
- EURO 162, 280 and IP panels
- Enforcer 32-WE
- V2 GSM

Each control panel/device connects via the RS485 bus terminals: D1-, D2+, D3, D4

Guidance

- Ensure wiring is done to the national wiring regulations in the country where the installation is taking place. In the UK, this is BS 7671 Requirements for electrical installations; IET Wiring Regulations (17th edition). If in doubt, consult a local qualified electrician.
- Ensure that a readily accessible disconnect device incorporated in the premises installation wiring shall be provided external to the equipment with a contact separation of at least 3,0mm and connected as closely as possible to the supply.
- Ensure that the wiring used to connect inputs to the Output Expander, is only connected to circuits operating at SELV voltage.
- When fixing external wires, ensure that means are provided in the installation to prevent the SELV or signal circuits from coming into contact with live parts of the power supply circuit. Wires shall be fixed near their terminal blocks.
- The end of stranded conductor shall not be consolidated by soft soldering at places where the conductor is subjected to contact pressure.
- On completion of wiring use tie-wraps to prevent any loose wires causing a safety hazard (material of cables tie shall be rated at least HB or better).
- Cables ties and hoses shall be separate for power supply cable and SELV wirings.
- Size of protective bonding conductors: minimum section 1.5mm².
- This product is for wall mounting installation only. Ensure that the mechanical mounting is suitable for the weight of the product. Use suitable fixings to fix to the surface and ensure that no pipes or wiring are present when drilling into the wall.

